

CROWN PX - Anteriori superiori



CROWN PX - Anteriori inferiori



EFUCERA PX - Posteriori 20°

SIMPLERR PX - Posteriori 20°



**ANTERIORI
CROWN PX****POSTERIORI****SUPERIORI****INFERIORI****EFUCERA PX****SIMPLERR
PX**

S43S

N41

28

M28

S41S

N32

28

M28

S42S

N31

28

M28

S51S

N42

30

M30

S51

N42

30

M30

S71

N71L

34

M34

S81

N81

(34)

M34

O31S

N31S

28

M28

O51S

N61S

32

M30

O61S

N61S

32

M30

O41

N32

28

M28

C41

N41

32

M30